```
1
     //assigning pin for the temperature sesor
2
    int temppin=0;
3
4
    void setup() {
5
    Serial.begin (9600);
    Serial.println("CLEARSHEET"); //setup so PLX-DAQ recieves data.
6
7
    Serial.println("CLEARDATA"); //aka talking to PLX-DAQ
    Serial.println("LABEL, TimeElappsed, TempC, TempF"); //Label the columns in the
8
    Excel spreadsheet
9
    Serial.println("RESETTIMER");
10
    1
11
12
     void loop() {
     Serial.print("DATA,"); //PLX-DAQ no knows that it will recieve data
13
14
15
     unsigned long ElapsedTime=millis(); //Reads how much time has elapsed since the
     beggining of he experiment
16
    ElapsedTime=ElapsedTime*0.001; //convert milliseconds to seconds
17
18
     int temp=analogRead(temppin); //Readiag data from the hot sensor. Stored as a 10bit
     number
     float voltage = temp * 5.0/1024;
19
     float tempC=(voltage - 0.5) * 100; //Converting 10bit number to the temperature.
20
21
     float tempF=((tempC*9/5)+32); //Convert to Fahrenheit
22
23
     //print data. Separate data print outs with by comma, so PLX-DAQ recognizes it as
     separate data
24
    Serial.print ( ElapsedTime ); //print how much time elapsed since the begginign of
     the experiment
25
    Serial.print(",");
    Serial.print( tempC ); //print the temp in Celsius
26
    Serial.print(",");
27
28
    Serial.println( tempF ); //print temp in Fahrenheit
29
30
    delay(1000); //repeat the loop every second (take data every second)
31
32
     }
33
34
```